













W-HPT- 30K/33K/36K/40K/50K Series
3-Phase Grid-tied Solar Inverters

USER MANUAL

CONTENTS

- 1. SYMBOLS ON THE LABEL 3
- 2. SAFETY AND WARNINGS..... 4
- 3. UNPACKING 5
 - 3.1 Scope of Delivery.....5
 - 3.2 Product Overview5
- 4. INSTALLING..... 7
 - 4.1 Installation Requirement7
 - 4.2 Mounting Location8
 - 4.3 Mounting.....9
 - 4.4 Installing the PE cable10
- 5. COMMISSIONING..... 12
 - 5.1 Safety Instructions12
 - 5.2 AC Wire Assembly and Connection12
 - 5.3 DC Wire Assembly and Connection13
 - 5.4 Residual Current Protection.....13
- 6. COMMUNICATION..... 14
 - 6.1 System monitoring via Datalogger - RS485/Wi-Fi /GPRS (Optional)14
 - 6.2 Output Power Control via Smart Meter15
- 7. START UP AND OPERATION..... 16
 - 7.1 Safety Check Before Start Up.....16
 - 7.2 Inverter LED Indicators17
 - 7.3 Display and Control Logics18
- 8. DISCONNECTING FROM VOLTAGE RESOURCES 19
- 9. TECHNICAL PARAMETERS 20
- 10. TROUBLE SHOOTING 22
- 11. SYSTEM MAINTENANCE..... 26
- 12. RESTARTS..... 27
- 13. CERTIFICATES..... 27
- 14. WARRANTY TERMS AND CONDITIONS..... 28

1. SYMBOLS ON THE LABEL

| | | | |
|---|--|---|--|
|  | DANGER, WARNING AND CAUTION |  | RECYCLABLE AND REUSABLE |
|  | HIGH VOLTAGE AVOID CONTACT |  | AVOID DAMP AND MOISTURE |
|  | HIGH TEMPERATURE AVOID CONTACT |  | SHIPMENT STACK LIMIT: 4 |
|  | CE MARKS |  | DO NOT DISPOSE WITH HOUSEHOLD WASTE |
|  | PROCEED OPERATIONS AFTER 5 MINUTES DISCHARGE |  | BREAKABLE ITEM |
|  | PLACE UPWARDS |  | USER MANUAL IN PACK |









2. SAFETY AND WARNINGS

1. All persons who are responsible for mounting, installation, commissioning, maintenance, tests, and service of WESTERN CO inverter products must be suitably trained and qualified for corresponding operations. They **MUST** be experienced and have knowledge of operation safety and professional methods. All installation personnel must have knowledge of all applicable safety information, standards, directives, and regulations.
2. The product must **ONLY** be connected and operated with PV arrays of protection class II, in accordance with IEC 61730, application class A. The PV modules must also be compatible with this product. Power resources other than compatible PV arrays **MUST** not be connected and operate with the product.
3. When designing or constructing a PV system, all components **MUST** remain in their permitted operating ranges, and their installation requirements **MUST** always be fulfilled.
4. Under exposure to sunlight, the PV array may generate dangerous output in DC voltage. Contacts with the DC wires, conductors and live components in the inverter may result in lethal shocks.
5. High voltages in inverter could cause lethal electrical shocks. Before proceeding any work, including maintenance and/or service, on the inverter, fully disconnect it from all DC input, AC grid and other voltage sources. There **MUST** be a 5-minute waiting time after the full disconnection.
6. The DC input voltage of the PV array **MUST** never exceed the maximum input voltage of the inverter.
7. **DO NOT** touch parts of the inverter during operation as heat will be induced and these parts will exceed 60°C.

3. UNPACKING

3.1 Scope of Delivery


Please inspect and check for completeness in the scope of delivery. Confirm with purchase order.

| | | | | | | | |
|---|---|---|---|---|---|---|--|
|  |  |  |  |  |  |  |  |
| Inverter | Mounting Bracket | Mounting Accessories | DC Plugs (Sealed) | AC Connector box | Meter Plug | Wi-Fi stick | Documents |
| 1 | 1 | 2 | *8 | 1 | 2 | 1 | 1 |
| *6 pairs for W-HPT-30K/W-HPT-33K/W-HPT-36K | | | | | | | |

3.2 Product Overview

The total size of W-HPT-30K/33K/36K/40K/50K is 580(width) ×435(height) ×242(depth) mm. It has 8 pairs (6 pairs for W-HPT-30K/33K/36K/) of PV input terminals and 3 communication ports. It also has a LED&LCD (or just LED, determined by user) for getting information and setting parameters at field.

The detail description is shown below:




| Mark Num. | Component | Description |
|-----------|-----------------------|--|
| 1 | LED&LCD or LED | Display and setting device at field |
| 2 | DC Switch | For switch on/off the inverter |
| 3 | PV Terminal (s) | Connected with PV Panel |
| 4 | COM1: Wi-Fi/GPRS | Alternative distant communication method |
| 5 | COM2: RS485 | For RS485 |
| 6 | COM3: METER/DRED | For smart-meter or DRED |
| 7 | AC Terminal | Connected with AC Grid |
| 8 | Secondary PE Terminal | For Grounding Protection |


4. INSTALLING

4.1 Installation Requirement

1. Please install the inverter(s) in places that can avoid inadvertent contact.
2. Installation method, location and surface must be fitting for the inverter's weight and dimensions.
3. Please install the inverter in an accessible location for operation, future maintenance and service.
4. The inverter performance peaks at ambient temperature lower than 45°C.
5. When installing in residential or domestic environment, it is recommended to install and mount the inverter on a solid, concrete wall surface. Mounting the inverter on composite or plaster boards or walls with similar materials would induce noise during its operation and is therefore not recommended.
6. DO NOT cover the inverter NOR place any objects on top of the inverter.
7. To ensure sufficient room for heat dissipation and maintenance, the clearing space between inverter(s) and other surroundings is indicated below for reference:




8. Avoid direct exposure to sunlight and rain and snow layup.



4.2 Mounting Location

1. DO NOT mount the inverter near any inflammable materials.
2. DO NOT mount the inverter near any explosive materials.



3. DO NOT mount the inverter on tilting surface over 15° backwards. Please mount the inverter on a vertical wall surface.
4. DO NOT mount the inverter on any surfaces tilting forward or to either sides.
5. DO NOT mount the inverter on a horizontal surface.
6. For easy installation and operation, please mount the inverter on a height that the display could match eye level.
7. The bottom side where all commissioning terminals are equipped MUST always point downwards.


4.3 Mounting

Moving the inverter:

1. Use machinery or manpower to move the inverter according to the situation on site.
2. It is recommended to move the inverter manually by at least two workers. Protective shoes, gloves and other PPE's (Personal Protective Equipment) are highly recommended. Focus on the pivot of the inverter and prevent tilting the inverter.
3. When using lifting machinery, thread the rope through two lifting handles on the upper side of the inverter. Pause when lifting the inverter up to 100 mm above the ground, ensure tightness of rope, then lift to the destination.


Wall-mounting the inverter

1. Use the mounting bracket as a template and drill holes of 10mm diameter and 70mm depth.
2. Fix the mounting bracket with the screws and expansion bolts packed in mounting accessories.
3. Hold up the inverter and tilt it slightly forward. Hang up the inverter and attach it to the mounting bracket. Check both sides of the heat sink to ensure its stably attached.
4. Use M5 screws (T25 screwdriver, torque 2.5 Nm) to attach the heat sink fins to the mounting bracket.
5. It is recommended to attach the anti-theft lock to the inverter. Lock diameter $\phi 4-5.5\text{mm}$ recommended.



4.4 Installing the PE cable

- 1. Insert the grounding conductor into the suitable terminal lug and crimp the contact.
- 2. Align the terminal lug with the grounding conductor and the ground washer on the screw. The teeth of the ground washer must be facing the housing.
- 3. Tighten it firmly into the housing (screwdriver type: T25, torque: 2.5Nm).



Information on grounding components:

| Object | Description |
|--------|--|
| 1 | Housing |
| 2 | Terminal lug with protective conductor |
| 3 | M6×16 screw SUS304 |

PE Conductor cross-section: 16 mm²

| AC Cable Cross-section | PE Cable Cross-section | Note |
|------------------------|------------------------|--|
| 16<S≤35mm ² | 16mm ² | Only suitable when the material of PE cable is aligned with other AC phase cables. In case the materials are different, please ensure the resistance is equivalent to the figure mentioned in the table. |
| S>35mm ² | S/2 | |

Cable Specifications

| No | Item | Type | Specifications |
|----|-----------------|--|---|
| 1 | PE cable | Single-core outdoor copper cable | <ul style="list-style-type: none">• Conductor cross-section: $\geq 16\text{mm}^2$ |
| 2 | AC Output cable | Outdoor copper cable | <ul style="list-style-type: none">• Conductor cross-section: L/PE: 16mm^2 N: 6mm^2• Cable outer diameter: 21-51 mm |
| 3 | DC Input cable | Standard outdoor PV cable, PV1-F Model recommended | <ul style="list-style-type: none">• Conductor cross-section: 4-6 mm^2• Cable outer diameter: 5-8 mm |
| 4 | Meter/DRED | Two-core outdoor shielded twisted pair cable | <ul style="list-style-type: none">• Conductor cross-section: 0.14-1.5 mm^2• Cable outer diameter: approx. 4-6 mm |

5. COMMISSIONING


5.1 Safety Instructions

1. Measure the frequency and voltage of grid connection and make sure they follow the inverter's grid connection specifications.
2. An external circuit-breaker on the AC side (or a fuse) at 1.25*AC rated current is strongly recommended.
3. Reliability of all earth connections must be tested and valid.
4. Before commissioning, disconnect the inverter and the circuit-breaker or fuse, and prevent accidental reconnection.

5.2 AC Wire Assembly and Connection


5.2.1 AC Commissioning

Step 1




Pull out the plastic rivet and remove the plastic sheet

Step 2



Press the cable into the appropriate terminal.
Use a screwdriver to lock the cable to the corresponding position and tighten the screws on the box following the indicated sequence (1~4)

Step 3



Assemble the box, threaded sleeve and swivel nut together

Note: Please ensure that the connector has been correctly installed!

5.2.2 AC Switch Types

Please install an individual 2-stage miniature circuit breaker according to the following specifications.

| Model | Maximum output current (A) | AC Breaker Rated current (A) |
|-----------|----------------------------|------------------------------|
| W-HPT-30K | 50 | 63 |
| W-HPT-33K | 55 | 63 |
| W-HPT-36K | 60 | 80 |
| W-HPT-40K | 66.7 | 80 |
| W-HPT-50K | 80 | 100 |

5.3 DC Wire Assembly and Connection

1. PV modules of the connected strings must be of: the same time, identical alignment and tilting angle.
2. Before commissioning and connecting the PV arrays, the DC switch MUST be open.
3. Parallel strings must have the same number of modules.
4. It is mandatory to use the DC connectors within package for the connection of PV arrays.
5. The polarity of the PV arrays MUST be compatible to the DC connectors of the inverter.
6. The DC input voltage AND DC input current of the PV array MUST never exceed the maximum input allowance of the inverter.

DC Commissioning:

| | | |
|--|--|--|
| <p>Step 1</p> <p>Strip off the insulation</p> <p>7mm 7mm 4-6mm²</p> | <p>Step 2</p> <p>Assemble the MC4 cable ends</p> <p>Positive terminal Negative terminal</p> <p>Assemble the D4 cable ends</p> <p>NOTICE</p> <p>Note: Don't crimp this part!</p> <p>Positive terminal Negative terminal</p> <p>Crimp pliers to cable ends</p> | <p>Step 3</p> <p>Assemble the connectors</p> <p>Positive Negative</p> <p>2.6-2.9 N·m</p> <p>Please check if the cables are securely installed by pulling outwards</p> |
| <p>Step 4</p> <p>Check the polarities of the PV strings</p> <p>Check the open-circuit voltage is less than inverter input limit 1100V</p> | <p>Step 5</p> <p>Remove the waterproof caps from PV terminals</p> <p>If there is an unused terminal, please seal it with the cap</p> | <p>Step 6</p> <p>Insert the connectors into the terminal till you hear an audible click.</p> <p>click click</p> |

5.4 Residual Current Protection

This product is equipped with residual current protection device internally, in accordance with IEC 60364-7-712. An external residual current protection device is not needed.


If the local regulation demands otherwise, it is recommended to install a 30mA Type B residual current protection device.

6. COMMUNICATION

6.1 System monitoring via Datalogger - RS485/Wi-Fi /GPRS (Optional)


6.1.1 Wi-Fi /GPRS Datalogger Installation

1. Unpack the Datalogger from package.
2. Unscrew the cap in COM1 port and plug the Datalogger in and tighten.
3. For user guidance and configuration of Wi-Fi Stick, please refer to the corresponding Wi-Fi Stick Guide manual, which is available in printed form inside Documents pack, or on Western CO. website at www.western.it/en




6.1.2 RS485/Smart Meter/DRED Connection

Step 1



Step 2

Insert the crimped conductors accordingly into their corresponding terminals and tighten the screws.



RS485 FOR COM2


- RS485 B1 ▶ PIN1
- RS485 A2 ▶ PIN2
- RS485 B2 ▶ PIN3
- RS485 A1 ▶ PIN4

Meter or DRED FOR COM3

- COMLOAD/0 ▶ PIN1
- RS485 A ▶ PIN2
- RS485 B ▶ PIN3
- REF GEN/0 ▶ PIN4


Step 3

Assemble the locking cap, threaded sleeve and swivel nut together.



Step 4

Screw the connector into the socket and tighten firmly.





When installing RS485, the COM sealing plate needs to be removed. All operation **MUST NOT** proceed until AC and DC power is securely disconnected and discharged to prevent electric shocks.

6.2 Output Power Control via Smart Meter

The inverter's active power output and efficiency could be monitored via the application of a smart meter.



Please refer to **EASTRON SDM630-Modbus V2 User manual** for its connection and baud rate settings.

7. START UP AND OPERATION

7.1 Safety Check Before Start Up




Please check before switching on any voltage resources connected to the inverter and closing inverter's DC switch:

1. Grid Voltage: Check the grid voltage at point of connection at the inverter complies with permitted range of the inverter.
2. Mounting Bracket: Check if the mounting bracket is properly and securely installed.
3. Mounting of the inverter: Check if the inverter is properly mounted and attached to the mounting bracket.
4. DC Connectors: Check if the DC connectors are installed correctly on terminals.
5. AC Connectors and Wire Assembly: Check if wires are assembled correctly on the AC side and if the AC connector is properly and securely installed. Check if the AC connector is firmly plugged into AC terminal.
6. Cables: Check if all cables are reliably connected. Check if the connections are effective, while the insulations are undamaged.
7. Groundings: Check all groundings using multimeter and if all exposed metal parts of the inverter are properly grounded.
8. DC Voltage: Check if the largest open-circuit voltage of PV arrays complies with the permitted range.
9. DC Polarity: Check if the wires from DC voltage resource are connected to terminals with correct polarity.
10. Grounding Resistance: Check if the grounding resistance of PV strings $>1\text{M}\Omega$ using a multimeter.

After all installation and checks, close the AC circuit-breaker, then the DC switch. The inverter will start to operate when DC input voltage and grid conditions meet the requirements of inverter startup.


7.2 Inverter LED Indicators

When the inverter operates, LED symbols on display have the following meanings:

| | |
|--|---|
|  POWER | <ul style="list-style-type: none"><input checked="" type="radio"/> ON Inverter Power ON and Feeding Power to Grid<input type="radio"/> Blink Inverter Power ON. Not Feeding Power to Grid<input type="radio"/> OFF Inverter Power OFF. DC Disconnected |
|  FAULT | <ul style="list-style-type: none"><input checked="" type="radio"/> ON Inverter is Faulty<input type="radio"/> OFF No Fault |
|  COM | <ul style="list-style-type: none"><input type="radio"/> Blink Communication Device Connected<input type="radio"/> OFF Communication Device Disconnected |

7.3 Display and Control Logics

When inverter starts up and operates, there is a control button beside LCD Display of the inverter. Please follow the logics listed below.



8. DISCONNECTING FROM VOLTAGE RESOURCES

Before proceeding any operations on inverter, please disconnect the inverter from all voltage resources as described in this manual.

Following these steps in described sequence are mandatory.

1. Disconnect miniature circuit-breaker and prevent from unintentional reconnections.
2. Open the DC switch and prevent the switch from closing unintentionally.
3. Use clamps to ensure there is no electrical current in DC wires.
4. Disconnect all DC connections and resources. Unplug the DC connectors, and DO NOT pull the cables.



5. Use multimeter to ensure the voltage on DC terminals of inverter is 0.
6. Unscrew cable and remove the AC connector.



Danger to life due to high voltages.

Inverter capacitors need 5 minutes to be completely de-energized.

When an error occurs, DO NOT remove the cover of the inverter onsite. Improper operations and attempts may induce electric shock.

9. TECHNICAL PARAMETERS

| Module | W-HPT-30K | W-HPT-33K | W-HPT-36K | W-HPT-40K | W-HPT-50K |
|---|------------------|------------|------------|------------|------------|
| INPUT/DC | | | | | |
| Max. PV Power（Wp） | 49500 | 49500 | 54000 | 60000 | 65000 |
| Max. Input Voltage（V） | 1100 | | | | |
| MPP Voltage Range（V） | 150-1000 | | | | |
| Min. DC Voltage（V） | 150/180 | | | | |
| Nominal DC-Input Voltage（V） | 620 | | | | |
| Max. Input Current（A） | 15 per string | | | | |
| Max. short DC current（A） | 22.5 per string | | | | |
| No. of independent MPPT inputs | 3 | | | 4 | |
| No. of PV strings per MPPT | 2 | | | 2 | |
| Max. inverter backfeed current to the array（A） | 0 | | | | |
| OUTPUT/AC | | | | | |
| Rated Power（W） | 30000 | 33000 | 36000 | 40000 | 50000 |
| Max. apparent AC power（VA） | 33000 | 36300 | 39600 | 44000 | 55000 |
| Rated grid voltage（Vac） | 380/400 | | | | |
| Rated power frequency（HZ） | 50/60 | | | | |
| Max. output current（A） | 50 | 55 | 60 | 66.7 | 80 |
| Max. output overcurrent protection(A) | 63 | 63 | 80 | 80 | 100 |
| Inrush current (Peak and duration)* | 31.6A@41ms | 31.6A@41ms | 31.6A@41ms | 31.6A@41ms | 31.6A@41ms |
| Max. output fault current(Peak and duration)* | 160A@525us | 160A@525us | 160A@525us | 160A@525us | 160A@525us |
| Adjustable displacement power factor | 0.8ind to 0.8cap | | | | |
| THDi at rated power | <3% | | | | |
| ** The inrush current and Max. output fault current are really test values. | | | | | |
| EFFICIENCY | | | | | |
| Max. Efficiency | 98.7% | 98.7% | 98.7% | 98.7% | 98.8% |

| | | | | | |
|-------------------------------------|---------------------------|-------|-------|-------|-------|
| Euro Efficiency | 98.3% | 98.3% | 98.3% | 98.3% | 98.4% |
| PROTECTION | | | | | |
| Anti-islanding Protection | Integrated | | | | |
| Input Reverse Polarity Protection | Integrated | | | | |
| Insulation Resistor Detection | Integrated | | | | |
| Residual Current Monitoring Unit | Integrated | | | | |
| Output Over Current Protection | Integrated | | | | |
| Output Short Protection | Integrated | | | | |
| Output Over Voltage Protection | Integrated | | | | |
| GENERAL DATA | | | | | |
| Dimensions(W*H*D) mm | 580*435*242 | | | | |
| Weight (kg) | 42.3 | | | | |
| Noise emission(typical) dB(A) | <45 | | | | |
| User Interface | LED&LCD or LED | | | | |
| DC connection type | D4 (MC4, H4 optional) | | | | |
| Communication | RS485/WiFi/GPRS(optional) | | | | |
| Cooling method | Smart Fan Cooling | | | | |
| Operating ambient temperature range | -25°C.....+60°C | | | | |
| Allowable relative humidity range | 0%~100% | | | | |
| Max. operating altitude(m) | 3000(>3000 derating) | | | | |
| Degree of protection(IEC 60529) | IP65 | | | | |
| Climatic category (IEC 60721-3-4) | 4K4H | | | | |
| Isolation method | Transformerless | | | | |
| Power loss in night mode | <1W | | | | |

10. TROUBLE SHOOTING

Earth Fault Alarm

This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring.

If an **Earth Fault Alarm** occurs, the **error code 6** will be displayed on the LCD. Red LED indicator will also light up.

Full Error Code and Corrective Measures

When the PV system does not operate normally, we recommend the following solutions for quick troubleshooting. If an error occurs, the Error code will be displayed on the inverter's screen, the red LED will light up. The corresponding corrective measures are as follows:

| Error Code | Fault Name | Description | Corrective Measures |
|------------|--|--|--|
| 1 | Functional fault in Micro-Controller Unit (MCU) | MCU abnormal self-check in start process | Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact service. |
| 2 | A faulty current sensor detected | AC current sensor detect current abnormal in the start process | Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact service. |
| 3 | Ground fault circuit interrupter (GFCI) sensor error | GFCI sensor self-check abnormal | Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact service. |
| 4 | A faulty grid relay detected | The difference between INV voltage and output voltage exceeds limit. | 1. Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. 2. If the fault persists, measure the phase to phase voltage and phase to zero and zero to ground voltage with a multimeter to ensure that the voltage is normal and the zero to ground voltage value should not be greater than 10V. 3. Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact service. |

| | | | |
|---|---|---|--|
| 5 | PV voltage too high | When the PV voltage of any circuit is greater than 1020V, it is determined as the PV voltage is too high. | Check the open-circuit voltages of the strings and make sure it is below the maximum DC input voltage of the inverter. If the input voltage lies within the permissible range while the fault occurs, please contact the service. |
| 6 | Surface insulation resistance error | In the process of power on and start-up, the insulation impedance of PV + and PV - to ground is detected. When the detection insulation impedance is less than 200kohm, it is judged as insulation fault. | <p>1. If it happens occasionally, it may be caused by rainy or humid environment. After the fault is eliminated, the inverter can resume normal operation without other actions.</p> <p>2. If there is continuous alarm, please check the PV array's insulation to ground and make sure that the insulation resistance to ground is greater than 200KΩ. Otherwise, visual inspection of all PV cables and modules. Make sure the grounding connection of the inverter is reliable.</p> <p>If all above are normal, please contact the service.</p> |
| 7 | Ground fault circuit interrupter (GFCI) exceeds the permissible range | residual current over the permission range | <p>1. Make sure the grounding connection of the inverter is reliable.</p> <p>2. Make a visual inspection of all PV cables and modules.</p> <p>If this fault is still shown, contact the service.</p> |
| 8 | Inverter temperature too high | Heat sink and internal environment temperature higher than 85 degree | <p>Please confirm:</p> <p>1. Whether the airflow to the heat sink is obstructed.</p> <p>2. Whether the installation site is in direct sunlight and ambient temperature around the inverter is too high.</p> <p>If all above is normal, contact the service.</p> |
| 9 | Utility grid disconnected | inverter detected grid voltage failed | <p>1. If it happens occasionally, it belongs to the short-time abnormality of the power grid, the inverter will return to normal operation after detecting that the power grid is normal, and there is no need to deal with it.</p> <p>2. If it cannot be recovered for a long time, please confirm:</p> <p>① whether the AC circuit breaker is disconnected</p> <p>② whether the AC terminal or fuse is in good contact</p> <p>③ whether the power supply line is normal</p> <p>If this fault is still being shown, contact the service.</p> |

| | | | |
|----|---|---|--|
| 10 | Grid voltage exceeds the permissible range | grid voltage exceeds the Safety regulations | <p>1.If it happens occasionally, it belongs to the short-time abnormality of the power grid, the inverter will return to normal operation after detecting the normal power grid, and there is no need to deal with it.</p> <p>2. In case of frequent occurrence but automatic recovery, please confirm if the grid voltage is outside the permissible range due to local grid conditions, try to modify the values of the monitored operational limits after informing the electric utility company first.</p> <p>3.If it cannot be recovered for a long time, please confirm:</p> <p>①whether the AC circuit breaker is disconnected</p> <p>②whether the AC terminal is in good connection</p> <p>③whether the power supply line is normal</p> <p>④whether the AC cable wiring (such as wire length and wire diameter) complies with the user manual guidance</p> <p>⑤whether the safety regulation settings are normal</p> |
| 11 | Grid frequency exceeds the permissible range | grid frequency exceeds the Safety regulations | <p>1.If it happens occasionally, it belongs to the short-time abnormality of the power grid, the inverter will return to normal operation after detecting the normal power grid, and there is no need to deal with it.</p> <p>2. In case of frequent occurrence but automatic recovery, please confirm if the grid voltage is outside the permissible range due to local grid conditions, try to modify the values of the monitored operational limits after informing the electric utility company first.</p> <p>3.If it cannot be recovered for a long time, please confirm:</p> <p>①whether the AC circuit breaker is disconnected</p> <p>②whether the AC terminal is in good connection</p> <p>③whether the power supply line is normal</p> <p>④ whether the safety regulation settings are normal</p> |
| 12 | DC component of the electricity exceeds the permissible range | the current exceeds 1A in stastic state and 4A in dynamic state | Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact the service. |

| | | | |
|----|---|--|--|
| 13 | EEPROM Error, e.g. transition disturbance | Micro CPU read EEPROM failed | Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact the service. |
| 14 | Internal communication fault | Master CPU communicate with slave CPU abnormal | Disconnect the inverter from the utility grid and the PV array, and reconnect it after LED turns off. If this fault is still being displayed, please contact the service. |
| 15 | Bus-voltage too high | Bus-voltage is greater than 1000V | Check the open-circuit voltages of the strings and make sure it is below the maximum DC input voltage of the inverter. If the input voltage lies within the permissible range while the fault occurs, please contact the service. |
| 16 | Bus-voltage too low | Bus-voltage is 20V lower than standard Bus-voltage | Check the open-circuit voltages of the strings and make sure it is below the maximum DC input voltage of the inverter. If the input voltage lies within the permissible range while the fault occurs, please contact the service. |
| 17 | DRM S9 Error | DRM switch S9 fault | Check the connection of DRM device. If the DRM device is connected normally while this fault occurs, please contact the service. |
| 18 | DRM S0 Error | DRM switch S0 fault | Check the connection of DRM device. If the DRM device is connected normally while this fault occurs, please contact the service. |
| 19 | N and PE voltage exceeds permitted range | | Check if the inverter is securely grounded. |

11. SYSTEM MAINTENANCE

For the inverter's long-term performance, it is suggested to maintain your inverter regularly:

NOTICE:

HEAT SINK MIGHT INDUCE INJURY

When the inverter is operating, the heat sink might exceed 60°C

- Please disconnect all electrical cables and connections. Wait for the inverter to cool down completely.
- Use compressed air cleaning or a soft brush to clean the inverter heat sink.
- ALL aggressive chemicals, cleaning solvents or strong detergents are FORBIDDEN

| Content | Maintenance Measures | Cycle |
|-----------------|--|--|
| System Cleaning | <ul style="list-style-type: none">• Check if the heat sink is covered and dusted• Maintenance of DC Switch can be performed at night. Turn the switch to ON and OFF positions for 4~5 times.• Use a wet cloth to clean the display | Annually OR Half a year |
| System Status | <ul style="list-style-type: none">• Inspect the enclosure for damage/deformation• Listen for abnormal noises during operation• Check if the parameters are normal during operation | Half a year |
| Commissioning | <ul style="list-style-type: none">• Check if the cables are loose• Check if the cable insulations are damaged, especially the parts in contact with metal surfaces | Half a year after first commissioning Annually OR Half a year |
| Grounding | <ul style="list-style-type: none">• Check if the cables are securely grounded | Half a year after first commissioning Annually OR Half a year |

12. RESTARTS

When reconnecting the inverter for electrical power supply, please follow the commissioning procedures and safety instructions as described in **Section 6** when applicable (e.g. DC Wires need to be reassembled).

Please run safety checks as described in **Section 7** before closing the DC Switch and starting up again,

13. CERTIFICATES

| | |
|-------------------------------------|--|
| Grid Standards | EN50549-1, AS/NZS4777.2, G98, G99, NBR16149, NB/T32004, IEC61727 |
| Safety Standards | IEC/EN62109-1/-2, NB/T32004 |
| Electromagnetic Compatibility (EMC) | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4, NB/T 32004 |



14. WARRANTY TERMS AND CONDITIONS

Period of validity of the warranty and affected products

Western CO. S.r.l. offers a ten-year warranty in the event of defects on entire range of W-HPT grid-tied inverters.

The default warranty period is 10 years from the date shown on the receipt confirming the purchase of the product and in any case may exceed 63 months from the date of production.

Keep in a safe place the Invoice (or the Fiscal Receipt) which may be requested by Western CO. S.r.l. whenever the warranty is used, otherwise the warranty obligations will lapse.

Technical assistance under warranty is provided exclusively at the only Western CO. S.r.l. technical support centre located in via Pasubio 1/3 - 63074 San Benedetto del Tronto (AP) – ITALY.

Excluded inspections and / or interventions in place under warranty.

Any references and contacts are available at this link:

<https://www.western.it/en/contacts>

Warranty terms and conditions

- This warranty covers faults in those products that can be proven to be a material and / or factory defect. The product will be repaired or replaced (at the discretion of Western CO. S.r.l.) in the Support Centre.
- Any interventions carried out by unauthorized Support Centres, as well as the alteration of the original plates or the cancellation of the Serial number (even partial), will automatically invalidate any warranty claim.
- The removal of the rivets for the opening of the inverter - if not expressly authorized by the Western Support Centre - will automatically invalidate any warranty claim.
- Western CO. S.r.l. is not liable for damage caused to the product by transport; the Buyer must ensure that the packaging is adequate and able to protect the product from breakage and impact caused by the transport itself. It is advisable to keep the original packaging.
- This warranty does not cover damage caused by: carelessness and negligence, incorrect and improper use of the product, any damage deriving from the use of the product

because of supply voltages different from that indicated, and any damage deriving from modifications made to the device is both on the electric and on the aesthetic parts.

- The use of the device outside normal safety conditions releases the Western CO. S.r.l. from all civil and criminal liability.
- Any damage caused by lightning, fire, force majeure of any kind excludes any liability of Western CO. S.r.l.
- Western CO. S.r.l. is not liable for consequential and consequent damages to the device, thus excluding any compensation in favour of the Buyer or the Retailer.
- Any technical or aesthetic changes, any improvements to the product that were put in place over time, do not require Western CO. S.r.l. to modify also the devices previously produced.
- If the device is replaced the remaining warranty period will be assigned to the regenerated device.
- At the end of the warranty period (10 years) or the termination of one of the causes that give the right to the warranty itself, the assistance will take place with the charge of the costs incurred for the replacement of parts and labor costs, subject to prior notice for repair quote.

Warranty assistance management

- The customer in need of assistance can contact the Western CO. S.r.l. support centre in the contacts indicated at this link:
<https://www.western.it/en/contacts/>
- The device in need of assistance must always be delivered or sent carriage paid (at the Customer's expense), upon registration and opening of a support ticket at the following link: https://supporto.western.it/?&lang=en_us
- Any shipments must be agreed with Western CO S.r.l. support centre and in any case may an unauthorized dispatch be carried out.
- The material must always be accompanied by the return document available on the support page or downloadable from the following link:
<https://www.western.it/en/warranty/> under Return note.

- The material under warranty will be returned to the customer within a maximum of 5 working days from the date of receipt at our warehouse. Any delays not dependent on Western CO. S.r.l. will be promptly communicated to the Customer.
- The method of resolving the complaint is at the sole discretion of Western CO. S.r.l.
- In case of device out of warranty, Western CO. S.r.l. will issue a repair quote (if possible) by sending it via e-mail to the Customer.

WESTERN CO. S.r.l.

Via Pasubio 1/3

63074 San Benedetto del Tronto (AP)

tel. (+39) 0735 751248 fax. (+39) 0735 751254

e-mail: info@western.it

web: www.western.it