

## Connector

▼ Grounding Rail Connector: Use 8 pcs 6.3x25mm self-drilling screw to fix



▼ Main Beam Connector: Use 8pcs 6.3x25mm self-drilling screw to fix



## Back Structure Installation Guide



## Installation Guide



① Screw Pile Installation



② Pre-assembled Mounting Parts Installation



③ Finish the pre-assembled installation



④ Grounding Rail and Back Structure installation



⑤ Finish Grounding Rail and Back Structure installation



⑥ Put the panel on that, use mid clamp and end clamp to fix them.